Standard and Tall Wall Cabinets















Please read these instructions carefully before proceeding.


This instruction is used in conjunction with the Installation Guide.

Important: Installation shall be carried out exactly according to the manufacturer's instructions otherwise a safety risk can occur if incorrectly installed.

Warning: In order to prevent cabinets overturning or falling down they must be used with the wall attachment device/s provided. Before fixing any cabinets to the wall, ensure the wall construction is capable of taking the weight of the loaded cabinet and that appropriate fixings are used. If in doubt, consult an expert.

Note: Wall fixing screws are not supplied due to different wall types requiring different fixings.

Caution: Some small pieces of hardware could be hazardous to small children. Keep all these items out of reach and do not leave children unattended in the assembly area.



How the cabinet is supplied.





Wall Cabinet (600mm wall illustrated, others similar)



94403516 nickel 94403517 black




x2 - Per frontal 94405709





1 pack per door 94381720 hinge nickel 95410006 hinge plate nickel 95410000 hinge black 94381788 hinge plate black







Wall Cabinet, (1000mm wall illustrated, others similar)







Note: Wall fixing screws are not supplied due to different wall types requiring different fixings.



x10 - Double cabinet 94403517 black



x2 - Per frontal



x4 - 64356003 Ø4x16 RHD



x2 - 92125900



x2 - 94402708



LH white - 95500016 RH white - 95500010 RH grey - 95500018 RH grey - 95500019



1 pack per door 94381720 hinge nickel 95410006 hinge plate nickel 95410000 hinge black 94381788 hinge plate black

Note: Wall fixing screws are not supplied due to different wall types requiring different fixings.

