



Larder Dresser

MAI00022 RO




Please read these instructions carefully before proceeding.
This instruction is used in conjunction with the Installation Guide.

Important: Installation shall be carried out exactly according to the manufacturer's instructions otherwise a safety risk can occur if incorrectly installed.


Warning: In order to prevent cabinets overturning or falling down they must be used with the wall attachment device/s provided. Before fixing any cabinets to the wall, ensure the wall construction is capable of taking the weight of the loaded cabinet and that appropriate fixings are used. If in doubt, consult an expert.

Note: Wall fixing screws are not supplied due to different wall types requiring different fixings.

Caution: Some small pieces of hardware could be hazardous to small children. Keep all these items out of reach and do not leave children unattended in the assembly area.



How the cabinet is supplied.




x16 94408309 Ø8x30	x18 92124206	x18 92124107	x2 - Per frontal 94405709
x12 94403516 nickel 94403517 black	x2 Ø4.5x47.5	x2 x4 - 64356003 Ø4x16 RHD	

G x2


Note: Wall fixing screws are not supplied due to different wall types requiring different fixings.

1a ① - ④ Trim panels before starting!




The dresser is supplied to suit a **12mm** worktop.
When using a thicker worktop an amount must be trimmed **OFF** eg;
30mm worktop minus **12mm** worktop = **18mm**
Trim **18mm** off the bottom of panels **A**, **B** and **F**
It is advised that raw edges must be sealed with edging tape, see stage 1d


1b ① - ④ Side panels (Standard illustrated, Tall similar)





1c ① - ④ Fixed panels x2




1d ① - ④ Back panels x2




2 ① - ④ (Standard illustrated, Tall similar)





3 ① - ④



4 ① - ④



5 ① - ④



6 ① - ④



x2



x2

7 ① - ④



G

G



x10

8 ① - ④ Secure to wall and connecting cabinets

Dresser to the front






Dresser to the rear



Note: Wall fixing screws are not supplied due to different wall types requiring different fixings.



x2



Connect the dresser from inside an adjoining cabinet.
Note: Fasten dresser on both sides where applicable.